

Product(S): P09000, P09001,
P09002, P09003, P09004,
P09005, P09006, P09007,
P09008, P09009, P09010

Rev: 21Aug12



INSTRUCTIONS FOR INSTALLATION

INCLUDED PARTS

- A. Bath Post base and rosette (1 set)
- B. Mounting bracket (1)
- C. Screws (2)
- D. Wall anchors (2)
- E. Allen wrench (1)
- F. Set screw - installed (1)



San Michele
P09000

MOUNTING INSTRUCTIONS ON DRYWALL

1. Determine the desired location for the Bath Post assembly (A).
2. Hold the Bath Post assembly to the wall, and mark the position of the rosette.
3. Place the mounting bracket (B) on the wall (inside where you marked the rosette position) and mark the location of the two screw holes.
4. Drill 5/8" holes in the wall.
5. Place the screws (C) through the mounting bracket and attach wall anchors (D) to the screws. Push the wall anchors through the wall, and tighten the bracket to the wall by tightening the screws. Pulling the mounting bracket away from the wall help secure the wall anchors while tightening the screws.
6. Attach the Bath Post assembly to the installed mounting bracket, top first, and tighten the set screw, using the enclosed allen wrench (E). Be careful to not over-tighten the set screw.

Note: Although basic mounting hardware is included, be sure to use the proper mounting hardware for your wall type. If unsure, consult your local hardware store. Attaching the mounting brackets to wall studs or to backing made of 1x2 or 2x4 is the best method for mounting your new hardware.

CARE

Clean only with a soft, dry cloth. To protect the finish, we do not recommend the use of polishes or abrasives. If you have any questions regarding your Vicenza Designs product, please contact your local dealer.

